



MP-O-E-25

Mounting instructions - Upper Mounting plate with ring screw for LL-12 and LL-25

Delivery scope:

- Mounting plate, 3 mm Aluminium, with onglued ring screw M6
- 4 screws M6x12 for fixing to the lift

Additionally needed:

- Ceiling fixing material

Make sure that the place to attach the lift has a load capacity that corresponds to the combined weight of the lift and the attached object - considering required safety factors (consult a structural engineer if necessary).

Required tools:

- Allen wrench size 4
 - Suitable tools for ceiling mounting
- (Torque for M6 screws: max. 7 Nm)



1.

Attach the mounting plate to the lift using the screws provided and an allen wrench size 4.



To comply with EU regulations ensure that LuxLift is connected to the ceiling with at least two independent attachment points.

Penny Hydraulics Ltd reserves the right to make changes to the technical data without prior notice. Penny Hydraulics Ltd assumes no liability for typesetting and printing errors. No claims can be derived from the information in this data sheet.